

Thrombin Activity Fluorometric Assay Kit

Product Information

Cat.No. Kit-0338

Product Overview

Thrombin activity assay kit utilizes the ability of Thrombin to proteolytically cleave a synthetic substrate and release a fluorophore, AMC, which can be easily quantified by fluorescence reader. This assay kit is simple, rapid and can detect Thrombin activity as low as 1 ng in samples.

Applications

Determine activity of pure Thrombin

Detect the activity of Thrombin in plasma

Storage

Store kit at -20°C, protected from light. Briefly centrifuge small vials at low speed prior to opening. Read entire protocol before performing the assay.

Thrombin Assay Buffer: Bring to room temperature before use.

Thrombin Enzyme Standard: Prepare a stock solution of Thrombin Enzyme (50 ng/μl) by adding 12 μl of Thrombin Dilution buffer to 4 μl of Thrombin Enzyme Standard. Mix. Aliquot & store at -80°C. Avoid repeated freeze/thaw.

Size

100 assays

Kit Components

Thrombin Dilution Buffer 1 ml

Thrombin Assay Buffer 15 ml

Thrombin Enzyme Standard 5 μl

Thrombin Substrate 0.5 ml

Materials Required but Not Supplied

96-well microplate with flat bottom. White plate is preferred for this assay.

Fluorometer

Tel: 1-631-559-9269 1-516-512-3133

Fax: 1-631-938-8127

Email: info@creative-biomart.org

45-1 Ramsey Road, Shirley, NY 11967, USA

Thrombin Activity Fluorometric Assay Kit

Assay Protocol

1. Sample Preparation: Add 2-50 μ l of sample containing Thrombin per well of 96-well plate and adjust the volume to 50 μ l with Thrombin Assay Buffer.
2. Standard Curve Preparation: Dilute Thrombin Enzyme Standard to 2.5 ng/ μ l by adding 38 μ l of Thrombin Dilution Buffer to 2 μ l of Thrombin Enzyme stock solution (50 ng/ μ l). Mix and add 0, 2, 4, 6, 8 and 10 μ l of diluted Thrombin Enzyme Standard (2.5 ng/ μ l) into a series of wells in a 96-well plate. Adjust the volume to 50 μ l with Thrombin Assay Buffer to prepare 0, 5, 10, 15, 20 and 25 ng/well of Thrombin Enzyme Standard.

Note: Store the diluted Thrombin Enzyme Standard solution at -80°C.

3. Substrate Mix: Prepare enough reagents for the number of assays to be performed. Prepare 50 μ l of Substrate Mix for Standard & sample wells.

Thrombin Assay Buffer 45 μ l

Thrombin Substrate 5 μ l

Mix and add 50 μ l of Thrombin Substrate Mix into Standard and sample well(s). Mix well.

4. Measurement: Measure fluorescence in kinetic mode for 30-60 min. at 37°C (Ex/Em = 350/450 nm). Choose two time points (T1 & T2) in the linear range of the plot and obtain the corresponding values for the fluorescence (RFU1 and RFU2).

5. Calculations: Subtract 0 Standard reading from all readings. Plot the Thrombin Standard Curve. Apply sample's Δ RFU to Thrombin Standard Curve to obtain corresponding Thrombin (B, in ng) and calculate the activity of Thrombin in the sample as:

Sample Thrombin Activity = B/V * Dilution factor = ng/ml = ug/L

Where B is Thrombin amount from Standard Curve (ng)

V is sample volume added into the reaction well (ml)